

PEAK® Screening

Window Screen Kit

Installation Instructions

Model 4229/4231 - 36" x 36" (91 cm x 91 cm)

Model 4232/4234 - 48" x 48" (122 cm x 122 cm)

Model 4235/4237 - 60" x 60" (152 cm x 152 cm)


⚠ WARNING No representation or warranty is given that your particular application of these products complies with relevant building codes. Therefore consult with professionals and local building officials before beginning work: (i) to ensure compliance with relevant building codes for your application; (ii) to identify appropriate safety gear that is to be used during installation such as a safety harness when working above ground; (iii) to ensure that the work area is free from utilities, services and hazards; and, (iv) to clarify any instructions or warnings that may not be clear. Work in a safe manner wearing protective gear such as gloves, eyewear, headwear, footwear and clothing. When using tools always comply with operation manuals and instructions. Metal may have sharp edges and could fragment or splinter during or as a result of handling or cutting. Do not use these products in connection with any substance that is or may be harmful or corrosive to the products. Inspect and maintain these products on a regular basis.

No member of The Peak Group of Companies (as defined at www.peakproducts.com) shall be liable for any loss or damage resulting from the improper installation or use of this product. In the unlikely event that any member of The Peak Group of Companies becomes liable for any loss or damage, the aggregate liability shall be limited to the retail purchase price of the product. Peak® products and the materials associated therewith are protected by patents, designs, copyright and/or trademarks. All trademarks are used under license from Peak Innovations Inc. May be subject to patent(s) or patent(s) pending.

Tools needed: Mitre saw (recommended) or hacksaw with non-ferrous metal cutting blade, scissors, painter's tape and flat work surface.

Kit contains: frame, corners, fiberglass screen, spline, spline tool, knife.


- 1.** Measure height and width of window screen opening.



- 5.** Cut screen to match overall frame dimension, allowing 2" overlap on all sides.




- 2.** Square-cut frames to fit in opening (note each corner adds 3/4").




- 6.** Tape two adjacent edges of the screen mesh to the frame. Using the spline tool, push spline and screen into groove opposite the taped edges. Remove tape and repeat process on remaining sides.



- 3.** Arrange frames and frame corners on a flat surface with the spline groove facing upwards. Insert frame corners into frames.



- 7.** Use knife to trim off excess screen.



- 4.** To hold frame in place, tape the center of each outside edge to the flat surface on all four sides.

